


# **INSTALLATION INSTRUCTIONS**

# Bath Filler (Excluding handles, unions and bases) - T10



#### **Important**

- We recommend that this product is installed by a qualified professional contractor. Such as a plumber who is certified by NVQ (National Vocational Qualification) or SNVQ (Scottish National Vocational Qualification) Level 3
- Please check this product immediately to ensure that it has not been damaged and is complete. Before installation, please make sure this product is the correct model and you have all the parts required for installation and using.
- All the taps in Burlington Range should be supplied with hot and cold water at balanced pressure. If not, then the mixing function will not work correctly. It is necessary to fit non-return valves on both hot and cold feeds pipe. These are not supplied.
- Please flush the water system to ensure that no metal swarf, solder, and other impurities can enter the taps.
- Turn off water supply before commencing work, this should be done at the isolating valves of inlet feeds if fitted or main stopcock.
- Please read these instructions carefully and keep it for future reference.

## Working pressure

The tap is suitable for both high and low pressure installation. To ensure that the tap works well under low water pressure, the cold water storage tank must be at least 2 meters above the installed position. The maximum static pressure is 10 bar, and operating water pressure is 5 bar. Where the operating water pressure above 5 bar, then a pressure reducing valve must be fitted.

## Straightener and aerator (alternative options)

The tap comes with a factory-fitted flow straightener for low pressure water systems. If the water flow is high, replace the factory-fitted flow straightener with the high pressure aerator supplied.

Use NEOPERL Key to unscrew the straightener in the Nozzle. Replace with the aerator provided, and screw back in nozzle tightly. (If you misplace the Neoperl key you can use the top of the aerator/straightener as a key)

## **Cleaning**

<u>Before use:</u> Unscrew the filter and allow the water to run freely for 5 minutes. Then screw the filter back in place.

<u>Periodically:</u> Using the key provided unscrew the nozzle and remove. Rinse it with cleaning running water until any loose debris is cleared. Then replace the nozzle and tighten with key provided.

#### <u>Maintenance</u>


We do NOT recommend you use any household cleaners to clean the product. Because these cleaners change substance or formula too frequently. The product should be always cleaned only with soapy water and rinsed with clean water and dried with a soft cloth.






FLOW STRAIGHTENER

AERATOR







- cartridge into the tap body a notch with a monkey spanner insert the tails into the holes on the wall. The fibre washer (not and then re-attach the tap head. supplied) may be inserted between the tail and the wall or tile
- If identify to install the Bath Filler on the Bath, you need install the
- T18 (Deck mounting unions) on the bath first.
- A) Remove the rubber washers and fixing nuts from the tails of Deck mounting unions.
- B) Insert the tails in two tap holes on bath.
- C) Tighten the rubber washer & the fixing nut from the under-side of | F) It is possible to use a G3/4 fixing nut (not supplied) to secure the wall the bath, and make sure the these two unions at 180mm centers.
- D) Tighten the Bath filler on joint nut and connect to the Deck mounting unions.
- mounting unions if they reach through a wall and the supply can then terminate in a swivel or flexible coupling.

[ D) Connect the water supplier pipes to both tails. From a front view,

E) Tighten the elbow part back with tails again. And make sure the

hot water on the left and cold water on the right.

outlets are upward and at 180mm centers.

G) Tighten the Bath filler on joint nut and connect to the Wall mounting unions.

F

I

I

surface to protect it.