





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA,AD, ..

Position



- | | |
|-------------------------|------------------|
| 1 = A 960872 XX | 20 = A 962062 NU |
| 2 = A 960231 XX | 21 = A 962063 XX |
| 3 = A 962998 NU | 25 = A 963587 NU |
| 4 = A 963432 NU | 26 = A 962064 XX |
| 5 = A 960462 NU | |
| 7 = A 960998 NU | |
| 8 = A 960587 NU | |
| 9 = A 963427 NU | |
| 10 = A 960871 XX | |
| 13 = A 963154 NU | |
| 14 = A 860458 NU | |
| 15 = A 860415 NU | |
| 17 = A 961810 NU (2x) | |
| 18 = A 960412 NU | |



MELANGE


A 4284 ..



0811/ A 865 738
 (+A 865 612)



Ideal Standard International BVBA
 Chaussée de Wavre, 1789 - box 15
 1160 Bruxelles
 Belgium

www.idealstandardinternational.com





	P bar				Q (3 bar)
	T °C				l/min 23

