





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD ..



Position

- 1 = A 960 690 XX
- 3 = B 960 473 XX
- 5 = A 960 691 XX
- 6 = A 963 022 NU
- 8 = A 960 145 NU
- 11 = A 960 692 NU
- 14 = A 961 182 NU (2x)
- 15 = A 960 133 NU




ATTITUDE
 A 4609 ..
















0811 / A 866 024
 (+ A 865 612)
 Made in Germany



Ideal Standard International BVBA
 Chaussée de Wavre, 1789 - box 15
 1160 Bruxelles
 Belgium

www.idealstandardinternational.com





	P	bar	MIN. 0,1		MAX. 5	Q (0,1 bar)
	T	°C	MAX. 80		65 40	