





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD...







Position

- 1 = A 961 494 AA
- 4 = A 960 701 AA
- 5 = A 960 702 AA
- 6 = A 963 427 NU
- 7 = A 960 587 NU
- 10 = A 963 432 NU
- 11 = A 960 462 NU
- 14 = E 960 641 AA
- 16 = A 860 415 NU
- 20 = A 960 914 AA
- 23 = A 963 651 NU




ATTITUDE
A 4614 ..




0116 / A 866 021
(+ A 865 612)
Made in Germany



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar	MIN. 0,1	MAX. 5	Q (0,1 bar)
	T	°C	MAX. 80	65 40	 l/min
					6,7

