





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /  
 Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi



Pos.	Part No.
1	A 861 019 AA
2	B 960 779 AA
3	B 960 780 NU
4	A 961 863 NU
5	A 861 156 NU
6	B 960 650 NU
7	A 963 651 NU
8	A 962 594 NU
9	A 961 182 NU
10	A 961 073 AA
11	F 960 697 AA
12	B 960 096 AA
13	B 0002 AA




**Tesi**  
 A 6581 .. A 6582 ..




**Ideal Standard**


1120 / A 868 866



**A6581**








**A6582**



Ideal Standard International NV  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

www.idealstandardinternational.com





	<b>P</b>	bar		MAX. 10		5		<b>Q</b>	(3 bar)
	<b>T</b>	°C		MAX. 80		65			
						55		8	22

	<b>P</b>			0	1	2	3	4	5
				°C	°C	°C	°C	°C	°C
		50°C	15°C	50	49	44	40	35	33
		65°C	15°C	65	63	57	50	44	40
		85°C	15°C	85	83	74	64	56	50