



HTMSP19XX - Hot Water Insulator Pipe



HTMSP5XX - Filter and Check Valve Assembly



HTMSP10XX - Battery Casing



HTMSP13XX - Sensor Cable



HTMSP7XX - Hot Water Blanking Assembly



HTMSP20XX - Check valve assembly removal tool



HTMSP14XX - Filter and Seal for Solenoid



HTMSP12XX - Tap Body End Cap



HTMSP2XX - Cartridge

Product Code	Description	Product Code	Description
HTMSP19XX	Hot Water Insulator Pipe	HTMSP20XX	Check valve assembly removal tool
HTMSP5XX	Filter and Check Valve Assembly	HTMSP14XX	Filter and Seal for Solenoid
HTMSP10XX	Battery Casing	HTMSP12XX	Tap Body End Cap
HTMSP13XX	Sensor Cable	HTMSP2XX	Cartridge
HTMSP7XX	Hot Water Blanking Assembly		



HTMSP21XX - 2 X Fibre Washers



HTMSP22XX - Cartridge Stop Rings



HTMFLUSH - Flushing Connector



HTMSP15XX - Cartridge Cover



HTMSP17XX - Sensor Complete



HTMSP18XX - Brass Elbow
for Solenoid



ID02500BAT - Batteries



ID09025/MIR - Sensor Eye



ID02812ELVK - Solenoid

Product Code	Description	Product Code	Description
HTMSP21XX	Fibre Washers	HTMSP18XX	Brass Elbow for Solenoid
HTMSP22XX	Cartridge Stop Rings	ID02500BAT	Batteries (x2)
HTMFLUSH	Flushing Connector	ID09025/MIR	Sensor Eye
HTMSP15XX	Cartridge Cover	ID02812ELVK	Solenoid
HTMSP17XX	Sensor Complete		



HTMSP3XX - Inlet Leg (Cold)



HTMSP24XX - Base flange



HTMSP4XX - Inlet Leg (Hot)



ID09025/4 - Transformer

Product Code	Description
<i>HTMSP21XX</i>	<i>Inlet Leg (Cold)</i>
<i>HTMSP22XX</i>	<i>Inlet Leg (Hot)</i>
<i>HTMSP24XX</i>	<i>Base Flange</i>
<i>ID09025/4</i>	<i>Transformer</i>

