Vellamo Boiling Water Taps

SAFETY BUTTON

Boiling water will only be dispensed when the safety button is depressed and rotated



COOL TOUCH SPOUT

The outer body of the tap and spout remain cool to touch as the boiling water travels through the centre of the body and spout and is separated by the normal cold water that sits around the outer perimeter of the neoprene boiling water tube.

Do not trap or twist the neoprene hose

During installation



Make sure the filter head is fitted In the correct direction. Which is indicated by arrows on the filter head. The flow should be from the tap to the tank on the cold return.

Do kink or crush the flexible hoses

Do not power the tank until the tank has been filled with water. Powering the tank without water will cause dry burn and will nullify your warranty