



# Shower Panel Instruction

Product must be installed in compliance with relevant Water Regulations and Byelaws




If you want higher hot water, please push the button and turn.




**Note: Installation is the same**

Note: Always check the walls for pipes and wires before drilling.

## Steps:




1. Drill the holes in the wall.
2. Insert the wall plugs inside the holes.
3. Tighten the screws to the wall with wall mounting brackets.











## Note!

Before assembly, flush the water supply pipes thoroughly to remove debris (allow the water to run with the main stopcock open for about 3 mins), otherwise dirt particles might affect the function of the shower panel!




Note: No harsh abrasive cleaning agents or materials can be used, use a clean damp cloth only.

## FOR INSTALLATION YOU MAY REQUIRE

			
Electric Drill	Tape	Wrenches	Pencil
			
Hammer	Sealing Tape	Screwdriver PH ⊕	Screwdriver PH ⊖

## Shower holder installation guide





NOTE: PLEASE CARRY OUT THE FOLLOWING STEPS,IF CLEANING /MAINTENANCE IS REQUIRED

## Thermostatic valve removal and installation

### Remove process

- ① Take off cap
- ② Loosen HEX screw off with allen wrench
- ③ Take off head
- ④ Take off ring
- ⑤ Unscrew the brass ring from the valve by tool
- ⑥ Remove the valve and clean: Run under warm water and use a toothbrush or similar to remove any debris or limescale

### Installation process

- ① Put the valve back
- ② Put brass ring on top of valve
- ③ Put ring in place  
Red color in a straight line
- ④ Press the button on the head and put on the head as below ensuring the screw hole pointing to the front
- ⑤ Use allen key to fix the HEX screw tightly
- ⑥ Put on cap